



**CAUTION**

Wiring multiple zones in parallel  
 Some actuators are not suitable for wiring in parallel  
 due to feedback from actuator. Please check with your  
 damper manufacturer to ensure your actuators are  
 suitable for parallel connection.

Refer to Brvis Advanced Network Programming Manual for Zone Programming